Windows Server Cannot Ping Client -Troubleshooting Steps

Check Network Profile on Client

- Open Settings > Network & Internet > Ethernet (or Wi-Fi)
- Click your active network
- Check the **Network profile** (Public, Private, or Domain)
- Note which profile is active

📞 Open Windows Defender Firewall with Advanced Security

- Press Start and search for Windows Defender Firewall with Advanced Security
- Open the application #

Enable ICMP (Ping) Rule Based on Network Profile

- Click Inbound Rules
- Find the rule named:\ File and Printer Sharing (Echo Request ICMPv4-In)
- If it exists for your active profile:
- Right-click -> Enable Rule Q
- If it does **not** exist:
- Click New Rule...
- Select Custom -> Next
- Protocol type -> ICMPv4 -> Next
- Leave Scope default -> Next
- Select Allow the connection -> Next
- Check only the active profile (Public, Private, Domain) -> Next
- Name it like | Allow ICMPv4 Ping [Profile] |-> Finish 🔝

Test Ping from Server

• On the Windows Server Command Prompt, run:

ping [Client IP Address]

• Example:

ping 192.168.100.3

If successful, the client is now responding to ping (ICMP) requests from the server.



